



NOTES:

1. SEE SIERRASCAPE FACING UNIT DETAIL FOR FACING MATERIALS AND DIMENSIONS.
2. USE SIERRASCAPE FACING UNIT TO FABRICATE CONTINUOUS CORNER. PROVIDE 24" (MIN.) OF SIERRASCAPE FACING UNIT IN BOTH DIRECTIONS AS MEASURED FROM THE CORNER BEND.
3. INSTALL ADJACENT SIERRASCAPE FACING UNITS TO PROVIDE 2.4" OVERLAP OF HORIZONTAL WIRES.

TOP OF SIERRASCAPE® WALL, FINISHING DETAIL

NOT TO SCALE

SIERRASCAPE® RETAINING WALL SYSTEM

MKE-SS-GE-FD-002.DWG